

The following files must be stored in the **System Files** folder:

File type	File extension
Feature Library files (TBC)	.fxl
Survey Style files	.sty
Geoid Grid files	.ggf
Combined Datum Grid files	.cdg
Configuration	.cfg
Projection grid files	.pjpg
Shift grid files	.sgf
UK National Grid files	.pgf
Broadcast RTCM transformation files	.rtd
Antenna files	.dat
GNSS Contacts file	.xml
Custom ASCII Import file definitions	.ixl
XSLT Custom ASCII Export Stylesheet files	.xsl
XLST Custom Stakeout Stylesheet files	.sss
Measure Codes Database files	.mcd
Coordinate System Database files	.csd

NOTE -

- *Language files (.lng) and sound files (.wav) are stored in the appropriate language folder, stored in **Program Files x86\Trimble\Trimble Access\General Survey\Languages\<language>**.*
- *Stakeout stylesheet files (.sss) and Custom Export stylesheet files (.xsl) can be located in the language folder or **System Files**. Translated Stakeout stylesheet files and translated Custom Export stylesheet files are typically stored in the appropriate language folder.*

Project folders

Each project is stored in its own folder in the **C:\ProgramData\Trimble\Trimble Data\Projects** folder. The **Projects** folder is created the first time you run the Trimble Access application.

Project files are stored in the appropriate **<project>** folder and can be used by any job in that project. Project files are typically map files, alignments, or control point files.