

Upgrading a GSR2700 ISX to 3.xxx

Requirements;

Fully charged GSR2700ISX receiver (battery charger can also be used)

PC with available serial port and terminal type program (If the PC does not have a serial port a USB to serial adapter can be used. We recommend the IOGEAR USB to Serial RS-232 adapter <http://www.iogear.com/product/GUC232A/>)

Serial to GPS cable part # 403-0-0036

Firmware and WinLoad Program

Directions:

1. Take contents of the zip file and unzip the all of the contents into a predefined folder.
2. Power down the ISX and plug the unit to your PC.
3. Run WinLoad select File - File Open then navigate to the folder where the 3xxx.hex file is located and select Write Flash. The unit will power on and the loader will take over, the authorization code will automatically populate the auth code field.
4. Wait for the process to end (the unit will reset its self then power back up).
5. To verify that the upgrade follow the directions in the GSR2700IS_ISX and HyperTerminal PDF file.

If you have any questions please feel free to contact us via email (support@topconsokkia.com).